



GISON Pneumatic Tools

GP-101MT Air Hydraulic Riveter



ADDING OIL METHOD (一) (二)



ADJUSTING LENGTH



AUXILIARY PARTS



PARTS LIST

✦ : Consuming Part

| Item No. | Part No. | Description | Qty. | Item No. | Part No. | Description | Qty. |
|----------|----------|--------------------------|------|----------|----------|------------------------|------|
| 01 | 101MT01 | Nosepiece Head | 1 | 33 | 101MT33 | Lock Nut | 1 |
| 1A | 101MT01A | Nosepiece 6.4 mm (1/4") | 1 | 34 | 101MT34 | O-Ring | 1 |
| 1C | 101MT01C | Nosepiece 4.8 mm (3/16") | 1 | 35 | 101MT35 | Cylinder Cap | 1 |
| 02 | 101MT02 | Frame Head | 1 | 36 | 101MT36 | Trigger Rod | 1 |
| 03 | 101MT03 | Jaw Case Head Part | 1 | 37 | 101MT37 | Trigger Level | 1 |
| 04 | 101MT04 | Jaws Case (12 mm) | 2 | 38 | 101MT38 | Valve Pusher Rod | 1 |
| 05 | 101MT05 | Jaw Pusher | 1 | 39 | 101MT39 | Air Cylinder | 1 |
| 06 | 101MT06 | Jaw Case Spring | 2 | 40 | 101MT40 | Frame Lock Nut | 1 |
| 07 | 101MT07 | Jaw Case Back Part | 1 | 41 | 101MT41 | Nipple Nut | 1 |
| 08 | 101MT08 | Case Lock Nut | 1 | 42 | 101MT42 | End Plug | 1 |
| 09 | 101MT09 | Valve Pusher | 1 | 43 | 101MT43 | Rubber Cushion | 1 |
| 10 | 101MT10 | E-Ring | 2 | 44 | 101MT44 | Jaw Case O-Ring | 1 |
| 11 | 101MT11 | Back Up Ring | 2 | 45 | 101MT45 | Washer Ring | 1 |
| 12 | 101MT12 | O-Ring | 4 | 46 | 101MT46 | Return Spring (Old) | 1 |
| 13 | 101MT13 | Air Vent Plug | 1 | 47 | 101MT47 | Frame Cap O-Ring | 1 |
| 14 | 101MT14 | Packing Seal | 1 | 48 | 101MT48 | Cap Nut | 1 |
| 15 | 101MT15 | Frame | 1 | 49 | 101MT49 | Bolt Plug | 1 |
| 16 | 101MT16 | Valve Ring Seal | 1 | 50 | 101MT50 | Spring Pin | 1 |
| 17 | 101MT17 | Oil Piston | 1 | 51 | 101MT51 | Level Pin | 1 |
| 18 | 101MT18 | O-Ring | 1 | 52 | 101MT52 | Screw Nut | 1 |
| 19 | 101MT19 | Back Up Ring | 1 | 53 | 101MT53 | Trigger | 1 |
| 20 | 101MT20 | Return Spring (Small) | 1 | 54 | 101MT54 | Spanner Gauge | 1 |
| 21 | 101MT21 | Frame Cap | 1 | 55 | 101MT55 | Spanner | 1 |
| 22 | 101MT22 | Dust Cap | 1 | 57 | 101MT57 | Hex. Wrench | 1 |
| 23 | 101MT23 | Hanging Clip | 1 | 58 | 101MT58 | Trigger Pin | 2 |
| 24 | 101MT24 | Air Valve Seal | 1 | 59 | 101MT59 | O-Ring | 1 |
| 25 | 101MT25 | O-Ring | 1 | 60 | 101MT60 | Seal | 1 |
| 26 | 101MT26 | Valve Sleeve | 1 | 61 | 101MT61 | Valve Spring | 1 |
| 27 | 101MT27 | O-Ring | 1 | 62 | 101MT62 | E-Ring | 1 |
| 28 | 101MT28 | Washer | 1 | 63-67 | 101MT63 | Universal Joint | 1 |
| 29 | 101MT29 | Air Piston Rod | 1 | 68 | 101MT68 | Air Hose Joint (5/16") | 1 |
| 30 | 101MT30 | O-Ring | 1 | 69 | 101MT69 | Air Hose Joint (1/4") | 1 |
| 31 | 101MT31 | Air Piston | 1 | | | | |