

9X998


# CORNER DRILL 40RCR

No.	PARTS No.	NAME OF PARTS	REQ'D No.	REMARK	No.	PARTS No.	NAME OF PARTS	REQ'D No.	REMARK
1	35659	HEAD	1		41	2908	SOCKET BEARING	1	
2	355101	TOP SHEET PACKING	1		42	35628	FEED SCREW SLEEVE	1	
3	355117	CYLINDER CASE	1		43	SPW04512	FEED SCREW SLEEVE PIN	1	
4	355110	TOP BEARING CASE	1		44	35630	FEED SCREW	1	
5	6203	TOP ROTOR BEARING	1		45	35631	FEED SCREW SLEEVE NUT	1	
6	12411	BEARING NUT	2		46	35442	FEED CENTER	1	
7	35506	CYLINDER	1		47	KP30018	FEED CENTER PIN	1	
8	355112	ROTOR	1		48	35668	THRUST WASHER	1	
9	601148	ROTOR VANE	5		49	TR425630	SOCKET CASE BEARING	1	
10	35602	ROTOR SHAFT	1		50	P1146	SOCKET PACKING	1	
11	K05035A	ROTOR SHAFT KEY	1		51	35667B	SOCKET CASE NUT	1	
12	35641	BOTTOM BEARING CASE	1		52	35639	CYLINDER CASE BOLT	4	
13	6203	BOTTOM ROTOR BEARING	1		53	W5060	CYLINDER CASE WASHER	4	
14	35606	ROTOR SHAFT NUT	1		54	N31126	CYLINDER CASE NUT	4	
15	SP 4510	KNOCK PIN	2		55	B760820	SOCKET CASE BOLT	4	
16	SP 3008	SPRING PIN	1		56	WS080	SOCKET CASE WASHER	4	
17	355104	BOTTOM SHEET PACKING	1		57	OC209	OIL PLUG	2	
18	35607	GEAR CASE JOINT	1		58	35660	REVERSE VALVE BUSH	1	
19	35609	GEAR CASE	1		59	35661	REVERSE VALVE	1	
20	6204	TOP ROTOR GEAR BEARING	1		60	35663	HOSE STEP	1	
21	35612	ROTOR GEAR	1		61	5B1/8	BALL	1	
22	627	BOTTOM ROTOR GEAR BEARING	1		62	KP4015	REVERSE VALVE PIN	1	
23	35610	INTERVAL GEAR	1		63	35672B	AIR HANDLE STEM	1	
24	KP4049	INTERNAL GEAR PIN	2		64	KP4008	AIR HANDLE STEM PIN	1	
25	35613	PINION HOLDER	1		65	35650	AIR HANDLE NUT	1	
26	35615	FIRST PINION	3		66	35675B	REVERSE VALVE JOINT	1	
27	35616	FIRST PINION SHAFT	3		67	35673B	JOINT BUSH	1	
28	35617C	DRIVE SHAFT	1		68	35648	JOINT PIN	1	
29	35619	SECOND PINION	2		69	5B3/8	STOP BALL	1	
30	35620	SECOND PINION SHAFT	2		70	12629	STOP SPRING	1	
31	6204	DRIVE SHAFT BEARING	1		71	35671B	AIR HANDLE SLEEVE	1	
32	2902	DRIVE SHAFT THRUST BEG	1		72	35654	AIR HANDLE VALVE	1	
33	35427	DRIVE SHAFT RING	1		73	KP4038	AIR HANDLE VALVE PIN	1	
34	6202	DRIVE GEAR BEARING	1		74	31749	AIR HANDLE SPRING	1	
35	35622	DRIVE SHAFT GEAR	1		75	31750B	AIR HANDLE CAP	1	
36	K04015A	DRIVE SHAFT GEAR KEY	1		76	H1005	HOSE STUD	1	
37	35624B	SOCKET CASE	1		77	H2004	HOSE STEM	1	
38	35625	SOCKET	1		78	35678B	ROCK COLLAR SPRING	1	
39	35626	SOCKET GEAR	1		79	35677	ROCK COLLAR PIN	1	
40	K603	SOCKET GEAR KEY	1		80	35676B	ROCK COLLAR	1	

356X6

9X998

# CORNER DRILL 65310



356X6