




吉生 **GISON**

GP-848 Air Speed Saw



PARTS LIST

✳ : Consuming Part

Item No.	Part No.	Description	Qty.	Item No.	Part No.	Description	Qty.
1	848001	Lock Nut	1	9	848009	Rear Barrel	1
2	848002	Washer	1	10	848010	Handle	1
3	848003	Leather Cup	1	11	848011	Front Barrel	1
4	848004	Washer Nut	1	12	848012	Chuck Guard	1
4A	848004A	Washer Nut and Sprint Assy.	1	13	848013	Ball Valve Lock	1
5	848005	Shifting Spring	1	14	848014	Lock Spring	1
6	848006	Plunger Rod	1	15	848015	Air Trigger Control	1
7	848007	Drive Shaft	1	16	848016	Felt Retainer	1
8	848008	Tool Chuck	1				