


吉生 GISON

GP-867T Air Screw Driver



PARTS LIST

✳ : Consuming Part

Item No.	Part No.	Description	Qty.	Item No.	Part No.	Description	Qty.
1	867T01	Anvil Collar	1	25	867T25	Rotor Blade	6
2	867T02	Holder Spacer	1	26	867T26	Cylinder	1
3	867T03	Spring	1	27	867T27	Rear End Plate	1
4	867T04	Quick Change Holder	1	28	867T28	Ball Bearing	1
5	867T05	Washer	1	29	867T29	Gasket	1
6	867T06	Oil Seal	1	30	867T30	Motor Housing	1
7	867T07	Hammer Case	1	31	867T31	O-Ring	1
8	867T08	Cpa Screw	4	32	867T32	Reverse Valve	1
9	867T09	Spring Washer	4	33	867T33	Valve Stem	1
10	867T10	Anvil Bushing	1	34	867T34	Throttle Lever	1
11	867T11	Spacer	1	35	867T35	O-Ring	2
12	867T12	Steel Ball	1	36	867T36	Valve Ball	1
13	867T13	Anvil	1	37	867T37	Spring	1
14	867T14	Hammer Cage	1	38	867T38	O-Ring	3
15	867T15	Hammer Pin	2	39	867T39	Reverse Knob	1
16	867T16	Hammer Dog	2	40	867T40	Spring Pin	1
17	867T17	Cam	1	41	867T41	Spring Pin	1
18	867T18	Rear Washer	1	42	867T42	Spring Pin	1
19	867T19	Clamp Screw	1	43	867T43	Air Inlet	1
20	867T20	Ball Bearing	1	44	867T44	Hanger	1
21	867T21	O-Ring	1	45	867T45	Regulator Housing	1
22	867T22	Front End Plate	1	46	867T46	Regulator	1
23	867T23	Spring Pin	3	47	867T47	Snap Ring	1
24	867T24	Rotor	1				